


MagicWave 190
MagicWave 230i
TransTig 230i

Spare parts list

EN

TIG Power source




Spare parts list: MW190 / MW230i / TT230i


MagicWave 190 /EF	4,075,218
MagicWave 190 /np	4,075,218,008
MagicWave 190 Set/EF	4,075,218,870
MagicWave 190 MV/B	4,075,218,631
MagicWave 190 MV/np	4,075,218,638
MagicWave 190 MV Set/B	4,075,218,871
MagicWave 190 MV Set/np	4,075,218,878
MagicWave 230 /EF	4,075,219
MagicWave 230 /np	4,075,219,008
MagicWave 230 MV/B	4,075,219,631
MagicWave 230 MV/np	4,075,219,638

TransTig 230 /EF	4,075,217
TransTig 230 /np	4,075,217,008
TransTig 230 MV/B	4,075,217,631
TransTig 230 MV/np	4,075,217,638

43,0004,5717 - NP (no plug)
43,0004,5534 - standard



43,0004,5665 - NP (no plug)
43,0004,5668 - cable Typ B NEMA 5-20
43,0004,5666 - cable Typ B NEMA 5-15
43,0004,5801 - cable Typ B NEMA L6-20



	M5x12	42,0401,1118
	M4x12	42,0401,1185
	M5x14	42,0401,1115



MW - 42,0409,0321
TT - 42,0409,0320



FRONIUS INTERNATIONAL GMBH

Froniusplatz 1, A-4600 Wels, Austria

Tel: +43 (0)7242 241-0, Fax: +43 (0)7242 241-3940

E-Mail: sales@fronius.com

www.fronius.com

www.fronius.com/addresses

Under <http://www.fronius.com/addresses> you will find all addresses
of our Sales & service partners and Locations